


Lecture 8 RICS and FLIM

Enrico Gratton

Laboratory for Fluorescence Dynamics University of Illinois at Urbana-Champaign




INTRODUCTION

Fluctuation Spectroscopy in cells is rapidly expanding

Advantages and challenges of FCS in cells

- Single point autocorrelation and cross-correlation provide information on molecular mobility and interactions
- PCH provides information on molecular concentration and brightness. Titration experiments in cells
- Most studies use fluorescent proteins
- Single point FCS is difficult to interpret
- Immobile fraction and bleaching perturb the correlation function Negative-going correlation curves Different cell locations show different dynamics!


Single point FCS of Adenylate Kinaseβ -EGFP



Diffusion constants ($\mu m^2/s$) of AK EGFP-AK β in the cytosol -EGFP in the cell (HeLa). At the membrane, a dual diffusion rate is calculated from FCS data. Away from the plasma membrane, single diffusion constants are found.

FCS: a closer look at existing techniques

Conventional FCS




Time resolution: µsec-msec

Monitors temporal fluctuations at a particular position in the cell to measure relatively faster diffusion (beam transit time in μ s).

Measurements contain single pixel information.

Temporal ICS



Time resolution: sec-min

Monitors temporal fluctuations at every point in a stack of 2-D images to measure very slow diffusion (Frame rates in the subsecond range).

Measurements contain spatial information (pixel resolution).

Can we put the two technologies together?

FCS in cells: Challenges

Need for spatial resolution: Spatio-temporal correlations

- Few years ago we proposed scanning FCS (circular orbit) as a method to measure the correlation function at several points in a cell simultaneously (Berland et al, 1995)
- ➤N. Petersen and P. Wiseman proposed image correlation spectroscopy (ICS) and recently, time-resolved ICS, similar in concept of scanning FCS in which a point in the image is measured repetitively

These methods have very high spatial resolution but limited time resolution

Scanning correlation in the millisecond Image correlation in the sub-second

Can we improve the temporal resolution to the level that we can measure freely diffusing molecules, and at the same time have high (pixel) spatial resolution?

FCS: novel ideas

The quick answer is **not yet**, but we can have a combination of very high time resolution with good spatial resolution.


In addition, there are other major benefits of the technique I will present:

- ➤ It can be done with commercial laser scanning microscopes (either one or two photon systems)
- >It can be done with analog detection, as well as with photon counting systems, although the statistics is different
- >The new technique provides a simple method to account for the immobile fraction
- ➤ It provides a powerful method to distinguish diffusion from binding

How does it work?

Temporal information hidden in the raster-scan image: the RICS approach

Images obtained in a laser scanning microscope contain temporal information because they are recorded sequentially pixel after pixel as opposed to a camera snap shot.




Situation 1: If the particle is not moving or slowly moving, a signal will be detected at position 1 and 2 but not at 3 and 4. In that case, the correlation between the fluorescence at different pixels will last for the extent of the PSF.

Situation 2: If the particle is moving fast, there is a chance to get some signal even at location 3 and 4. The spatial extent of the correlation will increase depending on the time scale of the diffusion.

RICS= Raster-scan Image Correlation Spectroscopy

Available time scales in RICS




Range of diffusion times accessible by different RICS techniques. Depending of the time scale of the process, pixel (μ s), line (ms) or frame (s) correlation methods can be used. Points long a line are microsecond apart. Points in successive lines are millisecond apart and frames are second apart.

The RICS approach: correlation functions

The mathematics and concepts for computation

What is different in RICS is the way the correlation function is calculated. We are all familiar with the concept of correlation function of a time series. Definitions:

$$G(\tau) = \frac{\langle \delta F(t) \delta F(t+\tau) \rangle}{\langle F(t) \rangle^2}$$



To calculate this function efficiently, the time series must be continuous. Generally, data points are collected every δt . The autocorrelation function is then calculated using either direct numerical algorithms or the FFT method.

If the time series is not continuous, but it has regular gaps the correlation function is modulated (convolution with a periodic square wave).

The RICS approach: 2-D spatial correlations

In a raster-scan image, points are measured at different positions and at different times simultaneously

If we consider the time sequence, it is not continuous in time If we consider the "image", it is contiguous in space

In the RICS approach we calculate the spatial 2-D spatial correlation function

(similarly to the ICS method of Petersen and Wiseman)

$$G_{RICS}(\xi, \psi) = \frac{\langle I(x, y)I(x + \xi, y + \psi) \rangle}{\langle I(x, y) \rangle^2}$$

The variables ξ and ψ represent spatial increments in the x and y directions, respectively

2-D spatial correlation can be computed very efficiently using FFT methods.

To introduce the "RICS concept" we must account for the relationship between time and position of the scanning laser beam.

The RICS approach for diffusion

We assume that the correlations due to spatial scanning and the correlations due to the dynamics at a point are "independent": i.e., the dynamics at a point is independent on the scanning motion of the laser beam

$$G_{RICS}(\xi, \psi) = S(\xi, \psi) \overset{\mathsf{X}}{G}(\xi, \psi)$$

Consider now the process of diffusion (as one example!). The diffusion kernel can be described by the following expression

Effect of diffusion

$$C(r,t) = \frac{1}{(4\pi Dt)^{3/2}} \exp(-\frac{r^2}{4Dt})$$


r

Given a particle at the origin at time zero, it can be found at time t at a distance r with a gaussian probability function with standard deviation that increases as a function of time and amplitude that decreases as a function of time

RICS: space and time relationships

At any position, the ACF due to diffusion takes the familiar form:


$$G(\xi, \psi) = \frac{\gamma}{N} \left(1 + \frac{4D(\tau_p \xi + \tau_l \psi)}{w_0^2} \right)^{-1} \left(1 + \frac{4D(\tau_p \xi + \tau_l \psi)}{w_z^2} \right)^{-\frac{1}{2}}$$



 τ_{p} and τ_{l} indicate the pixel time and the line time, respectively.

The correlation due to the scanner movement is

$$S(\xi, \psi) = \exp\left(-\frac{\frac{1}{2}\left[\left(\frac{2\xi\delta r}{w_0}\right)^2 + \left(\frac{2\psi\delta r}{w_0}\right)^2\right]}{\left(1 + \frac{4D(\tau_p \xi + \tau_l \psi)}{w_0^2}\right)}\right)$$



Pixel (log scale)


 δr is the pixel size. For D=0 the spatial correlation gives the PSF, with an amplitude equal to 1/N (Petersen and Wiseman). As D increases, the correlation (G term) becomes narrower and the width of the S term increases.

Performing a RICS measurement

Setup: any laser confocal microscope

- ➤ Acquire a raster scan image with a pixel time generally in the microsecond range and a line scan time in the millisecond range.
- ➤ Calculate the 2-D spatial correlation (or RICS analysis).
- Fit the 2-D autocorrelation with the previous equations.
- For circular or line scanning represent data as pseudo-image, one coordinate being spatial (along the line) and the other being time. This representation allows us to use the RICS approach. The fitting expressions are slightly different (see Digman et al, BJ 2005).


RICS: Fit of spatial correlation functions Simulations




256x256, 16 μs/pixel, 0.050 μm/pixel

RICS: Fits to spatial correlation functions

Olympus Fluoview300 LSM



Fit to Spatial ACF



Testing RICS

For molecules in solution, the method works fine. The same G(0) and the same D is obtained using single point FCS or the RICS calculation.

	Single	Circular	Raster
	point	scan	scan
D (mm²/s)	101	101	99
G(0)	2.10	2.04	2.06
D (mm²/s)	6.55	6.21	6.07
G(0)	2.10	2.00	2.08

Simulations: comparison between 3 different methods to recover D and G(0) for 2 different values of D (100 mm2/s and 6 mm2/s).

Conditions: Sampling frequency was 128 kHz for the fast moving particle and 32 kHz for the slowly diffusing particle. The orbit was sample at 128 points and the frame for the raster scan was 128x128 pixels. 1.6M points were simulated in each run irrespective of the sample frequency.

	Single point	Scanning FCS	Circular scan	Raster Scan
D(μm²/s)	5.9	8.4	8.2	8.6

Experimental data: fluorescent bead diffusing in solution

RICS benefits: better S/N at low concentrations

Repetition of 10 runs

Method (data acquired at 16 ms per point)	D in μm²/s	G(0)
Single point FCS	2.55 ± 0.92	1.69 ± 0.43
Circular scan	2.46 ± 0.14	1.57 ± 0.07
Circular scan (128 points per orbit)	2.46 ± 0.26	1.51 ± 0.06
Raster scan (128x128 pixels)	2.47 ± 0.31	1.54 ± 0.02

Repetitions of the same simulation (N=10) to estimate standard deviations. 100 particle diffusing in a plane of 128x128 pixels of $0.05\mu m$ each detected by different methods and recovered by the different equations. The length of the data stream is the same for each simulation, 320k points were simulated.

How we go from solutions to cells?

In cells we have an **immobile fraction**: molecules not moving during the course of the experiment.

If we perform the 2-D-image correlation operation of an image that contains immobile features, we obtain the transform (power spectrum) of the image. In this transform is impossible to distinguish the moving particles.

We need to separate this immobile fraction from the mobile

part before calculating the transform

How is this achieved?

RICS: subtraction of immobile features

Basic idea

In a "truly immobile" bright region, at each pixel the intensity fluctuates according to the Poisson distribution. However the time correlation of the shot noise is zero, except at channel zero. Also, if we cross-correlate the intensity at any two pixels, even if very close (within the PSF), the cross-correlation due to shot noise is zero.

Therefore, if we subtract the average intensity and disregard the zero time-space point, the immobile bright region totally disappear from the correlation function (in the first approximation).

After subtraction of the average image, a small number (equal to the image intensity is added).

Attention!!!!

This is not true for analog detection, not even in the first order approximation. For analog detection the shot noise is time (and space) correlated. Photon counting: ACF of a bright immobile particle




Analog detection: ACF of a bright immobile particle





Subtraction of the immobile fraction

The stack of images contains both mobile and immobile bright particles. The correlation function mostly reflects the shape of the immobile bright particles. After subtraction, the RICS only shows the fast diffusing molecules!



The stack of images contains only mobile particles. The RICS and the subtracted RICS are identical








original image


The same method can be used to subtract very slowly moving structure to account for the cell movement

RICS: Immobile Component Removal

Paxillin-EGFP in CHO K1



Fit to ACF with Immobile Component Removed



Digman et al. Biophys. J., 2005

RICS: Removal of slowly varying component


Very often cells (or parts of the cell) move.

Instead of subtracting the average (over the entire image stack), we could subtract a local moving average. This is equivalent to high-pas filtering of the image: only the fast changing features remain. In our software, it is possible to use different moving average lengths, depending on the speed of motion of the quasi immobile features.


Warning: The principle that the shot noise is time and space uncorrelated is not valid. After high-pass filtering, the intensity of one pixel carries to the next, both in time and in space, introducing correlations that were not there originally. However, the effect of filtering can be predicted and recognized.

Photon counting: ACF of a bright immobile particle

High pass filter effect: ACF of a bright slowly mobile particle



Example: GAP-GFP Small peptide that anchors GFP to the membrane



Original image (128x128) 700 frames


Average image of a 64x64 ROI

Recovered diffusion parameters for the mobile fraction

G(0) = 0.020

 $D = 0.50 \,\mu m^2/s$

Note that the diffusion coefficient recovered is an observed average over the entire ROI analyzed: the spatial resolution is dependent on the size of the ROI.



0.002

Fit of the 2-D spatial correlation

RICS: Spatio-temporal correlations

Diffusion or binding? (or blinking)


- Frequently, we obtain apparent diffusion coefficients below 0.01 mm2/s. These values are highly suspicious for single molecules or small aggregates!
- Experimentally it is difficult to distinguish between binding (exponential functions) and diffusion. PCH analysis often show that the amplitude fluctuations correspond to few fluorescent molecules.
- The original work of Elson, Magde and Webb in FCS was to measure binding.
- In solution is possible to predict the value of the diffusion; in cell this is problematic.
- The spatial correlation resulting from binding to immobile structures is different from diffusion.

RICS could identify binding (to immobile structures), blinking of diffusing particles and pure diffusion.

RICS: Models

Diffusion or binding? (or blinking)


For pure "binding equilibria" the function G(x,y) assumes a different expression



Line scan measurement (Fluoview300). Fit (black line) of pixel 190 data (red line) of the line scan experiment using A) diffusion equation D=0.032 μ m²/s and B) using exponential relaxation τ =0.63 s. The residues (blue lines) of the exponential fit are smaller and less correlated indicating a better fit using the exponential model

RICS: Models

Diffusion or binding? (or blinking)



Diffusion is faster than binding


The RICS correlation function should be identical to the PSF.

The amplitude should correspond to the brightness of the particle binding.

Adjacent points should be uncorrelated.

The binding kinetics is independent on the beam waist.

If there is only one binding site (or few), we could obtain directly the on-off statistics.



Diffusion is very slow

The RICS correlation function should be slightly broadened.

The amplitude should correspond to the brightness of the particle.

Adjacent points could be correlated.

The diffusion kinetics depends on the square of the beam waist

RICS: Models

Unimolecular reaction

$$G(\tau) = G_D(\tau, N_A + N_B, \tau_D) \left[1 + K \left(f_A - \frac{f_B}{K} \right)^2 e^{-\lambda \tau} \right]$$

 $K = k_f / k_b$ is the equilibrium coefficient; $\lambda = k_f + k_b$ is the apparent reaction rate coefficient; and fj is the fractional intensity contribution of species j

Note that diffusion modifies the shape of the spatial correlation function while binding equilibria gives always the same shape (the PSF) assuming that diffusion is fast compared to binding rate (either the on or the off rate)

RICS: Summary of spatial and time resolution

Resolution of the various scan methods

Method	Temporal resolution	Spatial Resolution
Line or circular scan	Millisecond	Pixel resolution (submicron)
Raster scan	Microsecond	Low resolution (typically 16 or 32 pixels), depends on the particle diffusion coefficient and the scan speed
Frame scan	Second	Pixel resolution (submicron)


RICS: Conclusions

There is a hidden time structure in the laser scanning images that can be exploited to obtain information about

- **>** Diffusion
- ➤ Velocity
- **≻**Brightness
- **≻**Aggregation
- ➤Blinking, binding-unbinding equilibria

We developed a general method to separate mobile from immobile fraction

This new development has great potential consequences for anyone interested in cellular imaging and dynamics



Globals by Enrico Gratton



images

The Globals program originally developed at the LFD for analysis of multiple files from spectroscopy is now available for image analysis. This new program analyzes FCS in images by the RICS approach, and lifetime images using the phasor approach.

Available in the Fall of 2005.

Price

\$1000 for Globals for Spectroscopy

\$1000 for Globals for Images

More information at www.lfd.uiuc.edu


GLOBALS for IMAGES derives from SimFCS

It is intended for analysis of images using physical models

Has the same minimization engine and error analysis of the original Globals Unlimited program

It has a very extensive library for analysis of

- ·FCS
- ·RICS
- •FLIM
- ·SPT



2-D and 3-D representations of data

Reads most of the file formats (B&H, FIFO, TIF, Methamorph, LSM, binary)

The emphasis is on model analysis (not image processing)

Ultrafast Analysis of Fluorescence Lifetime Images using the Phasor approach: Application to FRET analysis

Enrico Gratton

University of California at Irvine

Introduction

FLIM (fluorescence lifetime imaging microscopy) is becoming an important technique in fluorescence imaging microscopy.

FLIM is used for

FRET

Ion concentration

In a FLIM experiment, the fluorescence lifetime is measured at every single point in a image, generally 256x256 pixels

There are technical challenges regarding how to achieve the necessary data acquisition speed

A major problem is data analysis and interpretation

The challenges of FLIM

At every pixel there are contributions of several fluorescent species, each one could be multi-exponential.

To make things worse, we can only collect light for a limited amount of time (100-200 microseconds per pixel) which result in about 500-1000 photons per pixel.

This is barely enough to distinguish a double exponential from a single exponential decay.

Resolving the decay at each pixel in multiple components is a complex computational task "for experts only", partially alleviated by extensive use of global techniques.

Major issues with FLIM

- Rather difficult technique
- Long times for calculations
- Results depend on initial conditions
- Interpretation requires expertise

Can we avoid all these problems?

- No expertise necessary
- Instantaneous results
- Independent on initial choices
- Quantitative results
- Intuitive simple interface

A new approach

- Presently, the analysis proceed by resolving the exponential components at each pixel and by identifying molecular species with lifetime components.
- In the microscope environment, this process is prone to errors and depends on interpretation.
- We propose a change in paradigm: Use a different representation of the decay where each molecular species has its own unique representation and where each process (FRET, ion concentration changes) is easily identified.
- We need to go to a new "space".

The phasor space and the universal circle (From Star-Trek)




Where does this concept come from?

- When a fluorescent sample is excited with a sinusoidally modulated light, it responds with emission that has the same frequency but is phase shifted and demodulated with respect to excitation.
- Where does this concept come from??
- We need some math.

What is a phasor??

 A phasor is a quantity like a vector. Phasors can be added like vectors. You need to calculate the vector components and then add the components to obtain the vector sum



How to calculate the components g and s of a phasor from the time decay?

Frequency-domain components of a phasor. m and ϕ is what is measured

$$g_i(\omega) = m_i \cos(\varphi_i)$$

$$s_i(\omega) = m_i \sin(\varphi_i)$$


Time-domain components of a phasor. I(t) is what is measured

$$g_i(\omega) = \int_0^\infty I(t) \cos(\omega t) dt / \int_0^\infty I(t) dt$$


$$s_i(\omega) = \int_0^\infty I(t) \sin(\omega t) dt / \int_0^\infty I(t) dt$$

Note that I(t) is not resolved in components!!

Calculation of phase and modulation: frequency domain




Calculation of phase and modulation: time domain




We use identical formulas!!!

The algebra of phasors




Lifetime representation using phasors. **A:** Rotating vectors for excitation an demission with different phase delay. **B:** As the modulation frequency increases the end of the phasor describes a semicircle of radius ½ and centered at (½, 0). **C)** Mixtures of τ_1 and τ_2 must be on the line between τ_1 and τ_2 in proportion to their fractional intensity contribution. Given the experimental point and τ_1 we can find τ_2 and the fractional contribution. Given the experimental point, τ_1 must be less than τ_1 max and τ_2 must be greater than a τ_2 min.

How to distinguish two-exponential components from FRET?



Exponential components fall on the semicircle. **A**) Decay components made of multi-exponentials can fall any where. A linear combination of the two decays must fall in the line between the two decays. **B**) If there is quenching of τ 2 (the donor) the experimental values of experimental phasor cannot be on the line joining τ 2 to τ 1. Quenching trajectories can be very curved since τ 2 could become smaller that τ 1 depending on the FRET efficiency.

Example of FLIM analysis using phasors




Several regions the image can be identified corresponding to **a)** background (2 exponentials **b)** cell 1 bright (2 exponentials) **c)** cell 2 dim, **d)** cell junctions dim.

Image of cell expressing uPAR-EGFP and uPAR-MRFP receptor. Upon addition of a ligand, the receptor aggregates. FRET should occur at the cell junctions


The pitfall of "conventional" FLIM analysis

Image obtained using B&H 830 in our 2-photon microscope




Donor+acceptor+ligand. A) intensity image after background subtraction, B) $\tau_{\rm p}$ image C) $\tau_{\rm m}$ image.

Identification of FRET using the phasor plot




Selecting regions of the phasor diagram. Selecting the region in **A'** (donor +acceptor) the part in white lights up (**A**). Selecting the region in **B'** (autofluorescence) the part in white in lights up (**B**). The color scale in **B'** has been changed to better show the region of the autofluorescence. Selecting the region in **C'** (along the donor quenching line as shown in **D**) the part in white in at the cell junction lights up in **C**.

How to identify components?



Phasors for common fluorophores. EGFP (green), CFP (blue) mRFP1 (red), autofluorescence (at 880 nm -2photon excitation) violet. In any given pixel, mixture of EGFP and autofluorescence must be on the yellow line, mixtures of EGFP and mRFP1 must be on the red line. Mixtures of three of them must be inside the triangle with the corner in the 3 phasors.

How to identify processes?



Delay of the excitation of the acceptor due to FRET moves the acceptor phasor to the left (yellow arrow). If the delay is sufficiently long, the phasor could fall outside the semicircle. The donor phasor moves to the right (red arrow) due to quenching (shorter lifetime).

Features of the new approach

Many of the obstacles in FLIM data analysis can be removed. The accuracy of lifetime determination improved.

The speed of data analysis reduced to be almost instantaneous for an entire image and also using several (>10) images simultaneously.


The analysis is "global" over the image and across images.

The interpretation of the FLIM experiment is straightforward. Minimal prior spectroscopy knowledge needed.

The tool can be applied to all modes of data acquisition (frequency-domain and time-domain)

Raichu FLIM/FRET analysis


In MEF cells




(FRET)

http://www.biken.osaka-u.ac.jp/biken/shuyouvirus/e-phogemon/raichu-Rac.htm

Locating the CFP phasor




Life time of the background



TauP=2.4 TauM=4.6


Determining the cell autofluorescence phasor


Cells only, no CFP



TauP=1.557 TauM=3.03


Calculating FRET trajectories







Wt Raichu (1011variant) in MEF

0.5




Wt Raichu 1011 in MEF






TauP=1.9 TauM=2.6

Lifetime explorer and FRET efficiency calculator for multiple images




Images of cells 1,2:PAX-CFP, 3-8 Wt Raichu1011, 9-12 V12 Raichu, MEF cells



Examples: lon concentration in situ calibration

Excised skin sample



Acknowledgements

LFD

Michelle Digman Susana Sanchez

Istituto San Raffaele, Milano

Valeria Caiolfa Moreno Zamai Gabriele Malengo

University of Hamburg

Martin Behne

B&H

Wolfgang Becker